



Note: 12 Volt supply for flasher and bell is through relay contacts.